

UNIVERSAL400 TRAY

HOW TO USE

NOTE : The tray consists of a base and a receptacle.
 The receptacle is detachable for capsule transfer.

1. Stabilize the complete tray (base + receptacle) on a flat surface.
2. Place the top plate with the capsules in reverse on the tray receptacle. See picture 2 below.
 A rim is provided for this purpose. An end stop is also provided to lock the top plate in place.
To center the top plate on the support.
3. Push the capsules to drop them into the receptacle.
4. Remove the receptacle to collect your capsules when it is full.

i TO BE USED ONLY WITH OUR
 UNIVERSAL400 CAPSULE FILLER

